



FEATURES

- 1.Count Up Timer:Counts up to 99 min 59 sec then to 9999 min.
- 2.CountDown Timer:Counts down from 99 min 59 sec.
- 3.CountDown Timer:Counts down from 9999 min.
- 4.Clock:Displays time in hours (A and P) and minutes format.
- 5.Beep sound or silent operation.
- 6.Lock feature protects the values from accidentally resetting.

MODES CIRCULATION

- 1.Press M button to reach ▲ mode.
- 2.Press M button to reach ▼ MS mode.
- 3.Press M button to reach ▼ MM mode.
- 4.Press M button to reach ⌚ mode.

TO SET THE COUNTDOWN TIMER

▼ MS mode

- 1.Press M button to reach ▼ MS mode.
- 2.Press B button to increase (+) the seconds.
Press D button to decrease (-) the seconds.
- 3.Press A button to increase (+) the minutes.
Press C button to decrease (-) the minutes
- 4.Hold A or B or C or D button for rapid advance.

▼ MM mode

- 1.Press M button to reach ▼ MM mode.
- 2.Press B button to increase (+) the last 2 digits.
Press D button to decrease (-) the last 2 digits.
- 3.Press A button to increase (+) the first 2 digits.
Press C button to decrease (-) the first 2 digits.
- 4.Hold A or B or C or D button for rapid advance.

TO SET THE CLOCK

- 1.Press M button to reach ⌚ mode.
- 2.Press A or B button and ⌚ symbol will flash.
- 3.Press B button to increase the minutes.
Press D button to decrease the minutes.
- 4.Press A button to increase the hours.
Press C button to decrease the hours.
- 5.Hold A or B or C or D button for rapid advance.
- 6.Press M button to complete the setting and return to clock display.

HOW TO OPERATE

▲ mode

- 1.Press ◊ button to start counting.
- 2.Press ◊ button again to stop counting.
- 3.Press R button to reset to 0.

▼ MS/ ▼ MM mode

- 1.Press ◊ button to start counting.
- 2.Press ◊ button to stop counting.
- 3.Alarm sound for 30 seconds will activate upon completion and the display returns to the original setting.
- 4.Press R button to reset to the original setting.
- 5.Press R button again to reset to 0.

STOP symbol

- 1.Time in counting:STOP disappears.
- 2.Time stopped:STOP appears.
- 3.Countdown time set:STOP flashes.

LAST 3 MINS REMINDER

- 1.When the countdown reaches the last 3 minutes, the display will convert to countdown in seconds from 2 59, 2 58, 2 57...to remind you countdown time no matter which mode you are in.
- 2.The return to the original mode you were previously using, simple press mode button continuously until it reaches your desired mode.



Press S button repeatedly to show the symbol ⚡, ((•)), ((•)) ⚡ and blank successively.

- 1.When the ((•)) symbol appears, beep and alarm sound will activate.
- 2.When the ((•)) symbol disappears, beep and alarm will not sound.

BATTERY REPLACEMENT

- 1.Remove the battery cover on the back side of the body.
- 2.Remove and replace battery with type AAA.
- 3.Replace the battery cover and lock into place.