



FEATURES

1. Dual Tally Counters
 - Two separate tally counters.
 - Both counters count from 0 to 9999.
 - Calculates sum and difference between two counters.
 - Selects " - " symbol to subtract the values.
2. ⏻: Power on/off button.
3. Sleep mode activates after 2 hours of inactivity to save battery power.
4. ((•)): Beep confirmation sound is on when the symbol shows.
5. 🔒: Lock feature prevents accidental modification.

HOW TO OPERATE

1. Remove battery insulation film first.
2. Press A button to turn subtraction mode on/off. (" - " appears/disappears)
 - a. Press C button to increase or decrease the count by 1 in the upper row.
 - b. Press D button to increase or decrease the count by 1 in the lower row.

Note: When either counter reaches to 0:
 - Both counters will enter count-up mode. (" - " sign will disappear)
 - The device will alarm you with beep sounds.

3. Hold A button 2 seconds to show SUM of the two counters. (Σ symbol appears)

4. Hold B button 2 seconds to show DIFFERENCE of the two counters. (ΔF symbol appears)

TO RESET TO ZERO

- Press B button and the STOP symbols on the upper and the lower rows will flash.
- Follow step 1 to 3 while the symbols are still flashing:

1. Press C button to reset the counter on the upper row to 0.
 2. Press D button to reset the counter on the lower row to 0.
 3. Press B button again to return to the original display.
- * Note: The STOP symbol of the row will not flash if the counter in the row is already 0

⏻ POWER ON/OFF

1. Hold D button 2 seconds to power OFF the display.
2. The display will blank when no activity has been detected for 2 hours.
3. Press any button to power ON the unit.

((•)) 🔒

1. Hold C button 2 seconds to turn the beep sounds on/off. ((•)) symbol appears/disappears
2. Hold both C&D button 2 seconds to turn the lock feature on/off. (🔒 symbol appears/disappears)

Note: When the 🔒 symbol shows, every button will be locked. You will need to unlock the device before starting to use it again.

BATTERY REPLACEMENT

1. Remove the battery cover on the back side of the body with a coin or similar tool, using the arrows as direction indicators.
2. Remove and replace the battery with type LR44 or equivalent.
3. Be sure that " + " side is up.
4. Replace the battery cover and lock into place.