


## FEATURES


- Hour Timer: Counts up to 99H59M then to 9999H.  
Counts down from 99H59M or from 9999H.
- Minute Timer: Counts up to 99M59S then to 9999M.  
Counts down from 99M59S or from 9999M
- Clock: 12 hour or 24 hour format.
- (●): The (●) symbol appears to activate the beep and alarm sound.
- Lock feature protects the values from accidentally resetting.

## MODES CIRCULATION



- Press MODE button to reach HR mode.
- Press MODE button to reach MT mode.
- Press MODE button to reach (clock icon) mode.

## RESET TO ZERO




## Count Up Mode

- Press (diamond) button to stop counting.
- Hold RESET button 3 seconds to reset to 0.

## CountDown Mode

- Press (diamond) button to stop counting.
- Hold SET button 3 seconds and the digit will flash.
- Press RESET button to reset to 0 - 8888 or,
- Press RESET button to reset last 2 digits to 0 - 88:88.
  - Press SET button to shift digit.
  - Press RESET button to reset first 2 digits to 0 - 88:88.
- Press MODE button and display shows 0.

## 2d ↔ 4d




- 2d ↔ 4d When the display shows 0, press SET button to have alternation between 00:00 and 0000.
- ▲ ↔ ▼ When the display shows 0, press RESET button to have alternation between ▲ and ▼.




- Hold both SET and RESET button 3 seconds and the (●) symbol will either appear or disappear.
  - When the (●) symbol appears, each press of the button will have a beep sound.
  - When the (●) symbol disappears, each press of the button does not have a beep sound.
  - The last 30, 3, 2, 1 seconds remaining and alarm for 15 seconds upon completion will always sound even the (●) symbol disappears.
- Hold MODE button 3 seconds and the lock symbol will either appear or disappear.

## TO SET THE COUNTDOWN TIMER




- Press MODE button to reach HR or MT mode.
- Hold SET button 3 seconds and the digit will flash.
- Press SET button to shift the flashing digit.
- Press (diamond) button to advance the digit.
- Press RESET button to reset to 0.
- Press MODE button to complete the setting.

## TO SET THE CLOCK



- Press MODE button to reach (clock icon) mode.
- Hold SET button 3 seconds and minute digit will flash.
  - Press (diamond) button to advance the digit.
  - Hold (diamond) button 3 seconds for rapid advance.
  - Press RESET button to reset to 0.
- Press SET button and hour digit will flash.
  - Press (diamond) button to advance the digit.
  - Hold (diamond) button 3 seconds for rapid advance.
  - Press RESET button to reset to P 1(12h) or 0(24h).
- Press SET button to display 12h or 24h.
- Press (diamond) button to select 12h (A or P) or 24h.
- Press MODE button to complete the setting.

## HOW TO OPERATE



## Count Up Mode

- Press (diamond) button to start counting.
- Press (diamond) button again to stop counting.
- Press RESET button 3 seconds to reset to 0.

## CountDown Mode

- Press (diamond) button to start counting.
- Press RESET button to check the time from start.
- Press RESET button again to return to countdown timing.
  - Beep sound activates when the last 30, 3, 2, 1 seconds remain.
  - Alarm sound for 15 seconds activates upon completion.
- Press RESET button to check the time from start (▲ flashing).
- Press RESET button again to show overtime (▼ flashing).
- Press (diamond) button to stop counting.
- Press RESET button 3 seconds to return to original setting.

## BATTERY REPLACEMENT

- Remove the battery cover on the back side of the body with a coin or similar tool, using the arrows as direction indicators.
- Remove and replace the battery with type LR44 or equivalent.
- Be sure that "+" side is up.
- Replace the battery cover and lock into place.